

## Aerial Work Platforms Spare Parts (UAE Stock list)

Sr no.	Item	Description
1	JLGp-0080190	Adapter
2	JLGp-0140011	ALARM, SONALERT
3	JLGp-0181847	ANGLE,.12X1.00X1.50X2.00 A569
4	JLGp-0340046	BAND, MUFFLER 8"
5	JLGp-0380025	BASE, BOX
6	JLGp-0380025-R (incorrect unit type)	Ground Control Box
7	JLGp-04170886	Compression Spring, 04170886
8	JLGp-0440263	BEARING, FLANGE .750 DIA. PIN
9	JLGp-0561471	BLOCK,SPACER
10	JLGp-0641818	SCR CAP HH 5,.500-13X2.250
11	JLGp-0642024	SCR CAP HH 5,.625-11X3.000
12	JLGp-0682418	SCR CAP HH 8,.875- 9X2.250
13	JLGp-0701022	SCR CAP HH 8.8,10-1.50X70MM
14	JLGp-0902668	BRKT,LATCH PAWL
15	JLGp-0902790	BRKT,.38X3.25X7.73 A36
16	JLGp-0902919	BRKT, LH LOAD CELL GUARD
17	JLGp-0903530	BRKT, FILTER MOUNTING
18	JLGp-0962031	BUSHING, .38 X .62 X .31
19	JLGp-0962033	BUSHING, COMPOSITE 3"
20	JLGp-0962051	BUSHING, .50 X .81 X .38
21	JLGp-0962102	BUSHING, COMPOSITE 2 3/4
22	JLGp-0962152	BUSHING, COMPOSITE 1 1/2"
23	JLGp-0962297	BUSHING, COMPOSITE 3"
24	JLGp-0962348	BUSHING,COMPOSITE 1 1/2 ID X 2
25	JLGp-0962446	BUSHING, .38IDX.75ODX2.50 UHMW
26	JLGp-0962450	BUSHING,SPACER
27	JLGp-0962474 (incorrect unit type)	Bushing
28	JLGp-0962496 (incorrect unit type)	Washer 4740463 (4740463)
29	JLGp-1001091965	KIT(SERVICE),PLATFORM PCB
30	JLGp-1001092456	CONTROLLER,ES SYSTEM MODULE
31	JLGp-1001092497	DECAL,NO PIPE RACK ALLOWED
32	JLGp-1001093383	LATCH,LOCKING
33	JLGp-1001093626	FILTER,HYDRAULIC
34	JLGp-1001096705S	HARNESS,PLATFORM CABLE (1930)
35	JLGp-1001099926 (incorrect unit type)	Speed Sensor Kit-Perkins Engine (1001099926)
36	JLGp-1001102512	WASHER-SPEC,.313 X .250 NYLON
37	JLGp-1001102596	DECAL,MTB 460SJ
38	JLGp-1001102987	FILTER,CHARGE PUMP
39	JLGp-1001103489	HARNESS,VALVE & ENGINE

40	JLGp-1001108122	CONNECTOR,M12 TEE ADAPTER
41	JLGp-1001108496	DECAL,LEGEND (PLF)
42	JLGp-1001109345 (incorrect unit type)	KIT(SERVICE) ES PHP SWITCH (WAS 4360607) PER 2
43	JLGp-1001111017	ELEC ASSY BOX, ROBROY FIBERGLA
44	JLGp-1001118241 (incorrect unit type)	Seal Kit 2902074/1001118241 (1001118241)
45	JLGp-1001119452	SEAL,(KIT)
46	JLGp-1001119979 (incorrect unit type)	Seal Kit 1001119979/2902265 (1001119979/2902265)
47	JLGp-1001120104	SENSOR,PROXIMITY
48	JLGp-1001120141	VALVE,COUNTERBALANCE
49	JLGp-1001121657	DECAL,PLATFORM DISPLAY
50	JLGp-1001121801	DECAL,MAX CAP. 500LBS/227KG
51	JLGp-1001122242	COVER,LCD DISPLAY, REAR
52	JLGp-1001122508	DECAL,WARNING DUAL CAP.
53	JLGp-1001125293	Harness, LCD Display
54	JLGp-1001125978	SENSOR,TEMPERATURE
55	JLGp-1001131177	Fuse, Power Module
56	JLGp-1001131620	POWER TRACK,T/T TO BOOM
57	JLGp-1001131731 (incorrect unit type)	CARRIER HOSE & CABLE - RACK-I3
58	JLGp-1001133245	Valve, Manifold Mount Dual C/B
59	JLGp-1001133759	SENSOR,ANGLE
60	JLGp-1001138559	FTG-PIPE(CODED),MALE NPTF PIPE
61	JLGp-1001139654	DECAL,ULTRA LOW SULPHUR FUEL
62	JLGp-1001139995	KIT(SERVICE),SEAL_UNIVIS OIL
63	JLGp-1001139996	KIT(SERVICE),SEAL_UNIVIS OIL
64	JLGp-1001140564	FTG-STEM,BARBED 90 DEG
65	JLGp-1001141748	PIPE,EXHAUST OUTLET
66	JLGp-1001146795	DECAL,SEE MANUAL CE TRANS.
67	JLGp-1001146902	DECAL,CAPACITY
68	JLGp-1001146963	SENSOR,BEI ANGLE
69	JLGp-1001146984	DECAL,PLATFORM CONTROL
70	JLGp-1001147847	FILTER,AIR
71	JLGp-1001148972	VALVE,PROP POPPET
72	JLGp-1001151895	SENSOR,TILT
73	JLGp-1001155143	CABLE,BATTERY KIT
74	JLGp-1001156016	VALVE,COUNTERBALANCE
75	JLGp-1001156033	VALVE,COUNTERBALANCE
76	JLGp-1001158412	FILTER,HIGH PRESSURE
77	JLGp-1001159855	DECAL,MAX TIRE LOAD
78	JLGp-1001160169	KIT(SERVICE),SEAL
79	JLGp-1001160569	TANK,FUEL
80	JLGp-1001162880	PUMP,HYD.AUX BUCHER HYDRAULICS

81	JLGp-1001164709	VALVE,POPPET NORMALLY CLOSED
82	JLGp-1001168210	VALVE,COUNTERBALANCE
83	JLGp-1001168842	PIN,TELE CYL
84	JLGp-1001170847	SENSOR,PROX (M18) (12MM SEN)
85	JLGp-1001172217	DECAL,LIFT DIAGRAM
86	JLGp-1001175887	SEAL,KIT
87	JLGp-1001177297	VALVE,PLATFORM E/M600JP(LEV/
88	JLGp-1001177850	KIT(SERVICE),SHEAVE
89	JLGp-1001182256	VALVE,COUNTERBALANCE 1.5-1
90	JLGp-1001182570	SENSOR,PROX (M18)(12MM SEN)
91	JLGp-1001186552	VALVE,MAIN CONTROL
92	JLGp-1001187808	PUMP,AUXILIARY
93	JLGp-1001189882	DECAL,MSSO OPERATION
94	JLGp-1001192088	DECAL,GROUND CONTROL PANEL
95	JLGp-1001197408	DECAL,MSSO
96	JLGp-1001200458	PLATE,LATCH GUIDE
97	JLGp-1001215615	DECAL,LIFT DIAGRAM
98	JLGp-1001216060	DECAL,MAX TIRE LOAD
99	JLGp-1001216407	DECAL,DISPLAY PANEL
100	JLGp-1001216456	Kit, Flyboom Repair 680S
101	JLGp-1001218037	VALVE,PROP POPPET
102	JLGp-1001219601	SENSOR,TILT DUAL AXIS CAN
103	JLGp-1001219882	BRACKET,STRIKER,LATCH161629
104	JLGp-1001221486	TUBE,WELDMENT BOTTOM
105	JLGp-1001225432	FILTER,FUEL ELEMENT
106	JLGp-1001228092	CYL,LIFT
107	JLGp-1060846	CABLE,MANUAL DESCENT
108	JLGp-1061034	CABLE,MANUAL DESCENT (150")
109	JLGp-1061036	CABLE,MANUAL DESCENT (108")
110	JLGp-114370	Decal Sym Tip Over Batt
111	JLGp-1321384	CLAMP,HOOD
112	JLGp-1380151	CLIP, .67X1.00X.05
113	JLGp-1670842	COVER, TURNTABLE
114	JLGp-1671044	COVER,.12X6.27X9.07 A569
115	JLGp-1671228	COVER,ASSY TANK SIDE
116	JLGp-1671231	COVER,TANK
117	JLGp-1683976s (incorrect unit type)	Washer 4740463 (4740463)
118	JLGp-1684090s	Washer 4740463 (4740463)
119	JLGp-1684176S	Cyl. Rod Weldment
120	JLGp-1684306S	Cylinder Assy
121	JLGp-1684412S	Steer Cylinder, JLG 450AJ,400S,460SJ,3394,4394
122	JLGp-1702049	DECAL, MAN DESCENT (CE)
123	JLGp-1702155	DECAL, BATTERY DISCONNECT
124	JLGp-1702157	Decal Fuse Replacement
125	JLGp-1702241	DECAL, CABLE ROUTING

126	JLGp-1702868	DECAL, NO HANDS
127	JLGp-1703162	DECAL, FAN BLADE
128	JLGp-1703469	DECAL,MAX TIRE LOAD
129	JLGp-1703483	DECAL,MAX TIRE LOAD
130	JLGp-1703495	DECAL,MAX WHL LOAD
131	JLGp-1703797	DECAL,WARNING/DANGER PLAT
132	JLGp-1703804	DECAL,WARNING CRUSHING
133	JLGp-1703813	DECAL,WARNING BATT VENTILATION
134	JLGp-1703815	DECAL,ATTACH LANYARD HERE
135	JLGp-1703816	DECAL,DANGER/WARNING
136	JLGp-1703822	DECAL,MANUAL DESCENT INSTR
137	JLGp-1704445	DECAL,MAX TIRE LOAD
138	JLGp-1704589	DECAL,GLOW PLUGS
139	JLGp-1704726	DECAL, LOCK LATCH
140	JLGp-1704752	DECAL,MAX TIRE LOAD 7200#
141	JLGp-1704885	DECAL,WEBSITE
142	JLGp-1704995	DECAL,750#/500# CAPACITY (PLF)
143	JLGp-1705015	DECAL,LEGEND
144	JLGp-1705019	DECAL, SAFETY PROP
145	JLGp-1705034	DECAL,CAP(1020KG)(SINGLE EXT)
146	JLGp-1705038	DECAL,MODEL(3394RT)
147	JLGp-1705071	DECAL,750LB DUAL CAP (MTB)
148	JLGp-1705099	DECAL, CRUSHING HAZARD
149	JLGp-1705392	DECAL,CONFIGURATOR
150	JLGp-1705511	DECAL,HYD OIL LEVEL
151	JLGp-1705640	DECAL,CAPACITY 1000LB - 454KG
152	JLGp-1705648	DECAL,TIRE LOAD (1540LB/699KG)
153	JLGp-1705679	DECAL,INSPECTION (PLF)
154	JLGp-1705680	DECAL,DANG/WARN
155	JLGp-1705681	DECAL,ELECT (SIZ-PLF)
156	JLGp-1705686	DECAL,LEGEND (1930ES)
157	JLGp-1705693	DECAL,SAFETY PROP
158	JLGp-1705694	DECAL,CRUSHING 1930ES
159	JLGp-1705695	DECAL,ELECTROCUTION 1930ES
160	JLGp-1705704	DECAL,CAPACITY, 450KG, 320KG
161	JLGp-1705752 (incorrect unit type)	DECAL MTB CE 1705752
162	JLGp-1705753	DECAL,MTB CE (800A)
163	JLGp-1705977	DECAL, UPRIGHT LEVEL OVERRIDE
164	JLGp-1706098	DECAL,WARNING ETHER STARTING
165	JLGp-1706311	DECAL, TIRE LOAD(2070LB/939KG)
166	JLGp-1706312	DECAL,TIRE LOAD(2320LB/1052KG)
167	JLGp-1706350	DECAL, COVER
168	JLGp-1706670	DECAL, 1230ES MANUAL DECENT
169	JLGp-1706671	DECAL, 1230ES WHEEL LOAD
170	JLGp-1706679	DECAL, BRAKE RELEASE

171	JLGp-1706686	DECAL, 1230ES WARNING/CAP CE
172	JLGp-1706741	DECAL,BOOM CONTROL SELECT
173	JLGp-1810140	ELEC ASSY,SENSOR
174	JLGp-2080040 (USE JLGp-2080040-025)	Fastener
175	JLGp-2080063	FASTENER,NUT NYLON LOCK 1/4.25
176	JLGp-2220373	ADPT,ST S JIC/ORB 8-8 FG
177	JLGp-2221030	FTG, O-RING HEX NIPPLE
178	JLGp-2230027	FTG-STL TUBE, STRXSTR 12-12
179	JLGp-2540035	GROMMET,.44 ID X .94 OD
180	JLGp-2560088	HANDLE,GRIP
181	JLGp-2600246	HINGE,CONCEALED LIFT OFF
182	JLGp-2754311	HOSE ASSY,16G4HGMV
183	JLGp-2890279	KIT,HOOD STRIKER
184	JLGp-2890307	KIT,LOAD SENSE SYS LAMP
185	JLGp-2900477 (incorrect unit type)	Seal Kit 2900477 (2900477)
186	JLGp-2900714 (incorrect unit type)	Seal Kit 2900714 (2900714)
187	JLGp-2900768	BEARING REPAIR KIT
188	JLGp-2901549 (incorrect unit type)	Levelling Cylinder Seal Kit 2901549 (2901549)
189	JLGp-2901804 (incorrect unit type)	Kit Seal Upper Cylinder (2901804)
190	JLGp-2901805 (incorrect unit type)	Kit Seal 2901805 (2901805)
191	JLGp-2901902 (incorrect unit type)	Kit Seal Lavel Cylinder 450 (2901902)
192	JLGp-2901913	KIT, DSL GEN
193	JLGp-2902044 (incorrect unit type)	Tower Boom Cylinder Seal (2902044)
194	JLGp-2902073 (incorrect unit type)	Seal Kit 2902073 (2902073)
195	JLGp-2940126	LATCH, ROTARY PADDLE
196	JLGp-2940127	LATCH, RUBBER INSERT
197	JLGp-2940175	LATCH,T-HANDLE (LOCK)
198	JLGp-3160348	MOTOR,S-D DRIVE
199	JLGp-3220103	USE 1001257281
200	JLGp-3291005	NUT M10
201	JLGp-3300151	Nut Hex with Cap
202	JLGp-3300430	NUT-SPEC,ACORN
203	JLGp-3311005	NUT HEX,10-24 LOCK, 3311005-100
204	JLGp-3311505-100	NUT HEX,.312-18 LOCK,QTY=100
205	JLGp-3311605-100	NUT HEX,.375-16 LOCK,QTY=100
206	JLGp-3311605-1000	nut hex 375-16 ,qty-100
207	JLGp-3322002-025	NUT HEX,.625-18 LOW HT-25PCS
208	JLGp-3340453	PAD, .50 X 1.75 X 8.00 NYLTN
209	JLGp-3340787	PAD, .75 X 3.00 X 7.38 UHMW
210	JLGp-3340837	PAD,2.50X6300X.75 UHMW
211	JLGp-3340881	PAD,WEAR .62X2.50X6.00 UHMW
212	JLGp-3340916	PAD,ASSEMBLY WEAR
213	JLGp-3340922	PAD, ASSEMBLY WEAR
214	JLGp-3340929	PAD,ARM (.750)

215	JLGp-3422429	PIN, 1.00 DIA X 4.75 LG. 1045
216	JLGp-3422457	PIN, 1.25 DIA X 6.12 LG. 1045
217	JLGp-3422569	PIN, WELD MASTER TO FLY 1045
218	JLGp-3422577	PIN, 1.00 X 9.75 1045
219	JLGp-3422685 (incorrect unit type)	PIN
220	JLGp-3422701	PIN,1.00X8.87
221	JLGp-3422745	PIN,1.000/1.001DIA X 4.77LG PLTD
222	JLGp-3422754	PIN,STEER AXLE ATTACH
223	JLGp-3422792 (incorrect unit type)	Pin 3422792 (3422792)
224	JLGp-3422794 (incorrect unit type)	Pin1.25X11.50 (3422794)
225	JLGp-3422804	PIN,TELE CYL
226	JLGp-3422860 (incorrect unit type)	Pin, Ear Boom 3422860 (3422860)
227	JLGp-3422900 (incorrect unit type)	Pin
228	JLGp-3422922	PIN, PIVOT
229	JLGp-3422922 (incorrect unit type)	Pin Pivot 3422922 (3422922)
230	JLGp-3422944	PIN,ARM PIVOT 130K
231	JLGp-3422945	PIN,ARM PIVOT
232	JLGp-3422966	PIN,EXTENSION ROLLER
233	JLGp-3450806-025	PIN COTTER .25 X 1.50-QTY=25
234	JLGp-3520079	PLUG-SPEC, HOLE 1/2"
235	JLGp-3520080	PLUG-SPEC, HOLE 5/8"
236	JLGp-3572951	PLATE, RETRACT ROPE RETAINER
237	JLGp-3573181 (incorrect unit type)	Plate,Track Support (3573181)
238	JLGp-3573301	Plate
239	JLGp-3760115	RING, RETAINER
240	JLGp-3760133	RING, RETAINER
241	JLGp-3760348	RING, RETAINING
242	JLGp-3760387-012	RING, .09 X1.15X1.63-QTY=12
243	JLGp-3841013 (incorrect unit type)	Roller Rod (3841013)
244	JLGp-3841146	ROD, END
245	JLGp-3841287 (incorrect unit type)	Rod Keeper Shaft (3841287)
246	JLGp-3841443	ROD,TIE ROD END BEARING
247	JLGp-3900269	SCREW,SHOULDER BOLT .50X1.00
248	JLGp-3900283	SCREW-SPEC,3/8 BUTTON HEAD
249	JLGp-3900300	SCREW-SPEC,SK HD CP #10-32 X .
250	JLGp-3900323	PAN HD SCREW, 5/16-18X 2.00 LG
251	JLGp-3910612	SCR RD HD 6-32 X .750
252	JLGp-3931724	SCR CAP SOC HD .44-14 X 1.500
253	JLGp-3952020	SCR SOC SET .62-11 X 2.50 KNRL
254	JLGp-3960389	SEAL, HORIZ NOSE OF HOOD
255	JLGp-4060802	SHIELD, GUARD SWITCH
256	JLGp-4060805	SHIELD, FLEX TRIM
257	JLGp-4070895	SHIM, .06 X 1.75 X 6.00 STL
258	JLGp-4071012	SHIM,WEAR PAD
259	JLGp-4160187	SPRING,RUBBER

260	JLGp-4240099S	STRAP, TIE 11.00
261	JLGp-4300140	STUD, 5/16-18 X 4.00 LG.
262	JLGp-4360069	SWITCH, CIRCUIT BREAKER 10A
263	JLGp-4360202S	SWITCH, -TOGGLE
264	JLGp-4360436	SWITCH, FUEL LEVEL
265	JLGp-4360517 (incorrect unit type)	Proximity Switch (4360517)
266	JLGp-4360538	SWITCH, MEMBRANE
267	JLGp-4460509	TERMINAL, SOCKET
268	JLGp-4460836	TERMINAL, CONN 12 POS
269	JLGp-4460876	TERMINAL, CONN BLUE
270	JLGp-4460943	TERMINAL, PIN 20-16 GA GOLD
271	JLGp-4460950	Terminal, Connector Housing
272	JLGp-4460968	TERMINAL, CONN STRN RELIEF
273	JLGp-4461052	TERMINAL, 25 POS SPLASH PROOF C
274	JLGp-4461070 (incorrect unit type)	Terminal, Connector 3Pos (4461070)
275	JLGp-4461095	TERMINAL, PLUG
276	JLGp-4567123	TUBE, FEMALE JIC (90 DEG)
277	JLGp-4640489	VALVE, C'BALANCE
278	JLGp-4640936 (incorrect unit type)	Valve, Motor Control (4640936)
279	JLGp-4641032	VALVE, GRESEN NDX2918 HOLDING
280	JLGp-4641162 (incorrect unit type)	Valve, C Balance (Was P/N 4640525) (4641162)
281	JLGp-4641173	VALVE, SOLENOID (POPPET)
282	JLGp-4641175 (incorrect unit type)	Platform Manifold Valve (4641175)
283	JLGp-4641234 (incorrect unit type)	Cartridge Valve
284	JLGp-4641254	VALVE, PROPORTIONAL W/INTERNAL
285	JLGp-4641265	VALVE, 3 WAY CAM OPERATED P.A.
286	JLGp-4641285	VALVE, SHUTTLE
287	JLGp-4641370	VALVE, LIFT CYLINDER
288	JLGp-4700038	PAD, INNERMID BTM
289	JLGp-4740158	WASHER, BRNZ 3.00X2.011 .25
290	JLGp-4740253	WASHER, STL LOCK TW110
291	JLGp-4740263	WASHER, SPECIAL
292	JLGp-4740438	WASHER, 1.31 X 2.00 X .095
293	JLGp-4740537	WASHER-SPEC, THRUST, .0625
294	JLGp-4750600	Flat Washer
295	JLGp-4760600	Washer
296	JLGp-4761000	Washer
297	JLGp-4812200	WASHER, FLAT METRIC (CODED)
298	JLGp-4844815	Weldment Pivot, 1001169384
299	JLGp-4846573S	WELD, SUPPORT
300	JLGp-4892400	WASHER, HARDENED
301	JLGp-4892600	WSH HARD 1.00 1.031 1.625 .187
302	JLGp-4922379	WIRE, PLATFORM HARNESS
303	JLGp-4922437	HARNESS, PLATF CNTRL W/ JACKS
304	JLGp-4922467	HARNESS, MAIN BOOM CABLE(660SJ)

305	JLGp-4922526	HARNESS, PLATFORM CONTROL BOX
306	JLGp-4922566	CABLE, CONTROL CABLE 800S 85'
307	JLGp-4922569	WIRE LOWER BOOM HARNESS 800'S
308	JLGp-4922705	HARNESS,ANALYZER, BLAM BOARD
309	JLGp-4922768	HARNESS, PLATFORM CONTROL BOX
310	JLGp-4922869	HARNESS, EIM LOADCELL
311	JLGp-4922870	HARNESS,PLATFORM BOX
312	JLGp-4923397	HARNESS,VALVE
313	JLGp-4923478	HARNESS,GLOW PLUGS 3 CYL
314	JLGp-5241200	WASHER,THRU HARDENED METRIC
315	JLGp-66812	Button Push (Emergency Switch)
316	JLGp-70000043	DIPSTICK
317	JLGp-70000812	PIN, DISCONNECT CAP
318	JLGp-70000814	CAP, DISCONNECT
319	JLGp-70000815	ASSEMBLY, COVER
320	JLGp-70000816	PAD
321	JLGp-70000832	SEAL
322	JLGp-70000969	SEAL, SHAFT
323	JLGp-70000973	GASKET, STATOR TO GEAR HOUSING
324	JLGp-70000974	GASKET,GEAR HSG TO GEAR HSG
325	JLGp-70000977 (incorrect unit type)	SEAL KIT
326	JLGp-70000978 (incorrect unit type)	Pump Kit
327	JLGp-70001265	KIT, MOTOR COVER
328	JLGp-70001368	ASSEMBLY, COVER
329	JLGp-70001396	PUMP, WATER
330	JLGp-70001398	Gasket, Water Pump; 145996921, U45996990
331	JLGp-70001697	SCREW, COUNTERSUNK CAP
332	JLGp-70001872 (incorrect unit type)	HARNESS ENGINE (70001872)
333	JLGp-70001982 (incorrect unit type)	Kit Adapter Maintenance seal
334	JLGp-70002074	TUBE, HYDRAULIC
335	JLGp-70002113	BREATHER, FILLER(3 MICRON)
336	JLGp-70002219	RING, INTERNAL SNAP
337	JLGp-70002247	KIT, COVER
338	JLGp-70002249	KIT, BRAKE
339	JLGp-70002277	KIT, SEAL
340	JLGp-7000232 (incorrect unit type)	WASHER THRUST-1H(SPACER)-7000232 (7000232)
341	JLGp-70002386 (incorrect unit type)	coil
342	JLGp-70002413	CARTRIDGE
343	JLGp-7000246	INTERNAL GEAR
344	JLGp-7000288 (incorrect unit type)	SWING MOTOR SEAL LIP-7000288 (7000288)
345	JLGp-70003099 (incorrect unit type)	Seal Kit
346	JLGp-70003465	SENSOR
347	JLGp-70004404	CARTRIDGE
348	JLGp-70004406	CARTRIDGE
349	JLGp-70004451	KIT, SEAL



350	JLGp-70004489	KIT, GEARBOX SEAL
351	JLGp-70004652	CARTRIDGE
352	JLGp-70004960	Seal Kit, JLG 520
353	JLGp-70005096	CARTRIDGE
354	JLGp-70005576	COIL
355	JLGp-70006652	ALTERNATOR
356	JLGp-70024513	SENSOR CABLE
357	JLGp-70024912	GASKET
358	JLGp-70025200	SEALING RING, WATER PUMP
359	JLGp-70025210	CONTROL UNIT
360	JLGp-7003790	CAP, STEERING SWITCH
361	JLGp-7003946 (incorrect unit type)	ETURN SPRING (7003946)
362	JLGp-7003973	HANDLE, HALF
363	JLGp-7003980	SCREW, 3 X 12
364	JLGp-7005881 (incorrect unit type)	Seal Kit 7005881 (7005881)
365	JLGp-7007640	WHEEL STUD FAIRFIELD
366	JLGp-7010406	LIP SEAL
367	JLGp-7010542	Cartridge Valve. 10837580
368	JLGp-7011016	COUPLING
369	JLGp-7011044	GASKET
370	JLGp-7012693 (incorrect unit type)	Kit Seal 7012693 (7012693)
371	JLGp-7012947 (incorrect unit type)	Cartridge(Emergency Descent)-Mrio (7012947)
372	JLGp-7016328	FILTER, FUEL... (DEUTZ)
373	JLGp-7017158 (incorrect unit type)	Bucket/Platform Rotator Seal Kit (7017158)
374	JLGp-7017421	CARTRIDGE
375	JLGp-7017422 (incorrect unit type)	Cartridge valve
376	JLGp-7017433 (incorrect unit type)	Cartridge, Valve
377	JLGp-7017451 (incorrect unit type)	Coil Of 4641234 7017451 (7017451)
378	JLGp-7017454 (incorrect unit type)	Cartridge Valve 7017454 (7017454)
379	JLGp-7017959	BAND, PIPE
380	JLGp-7018991	COIL, GZ45 12V
381	JLGp-7019141	MECHANICAL ASSEMBLY, JS5
382	JLGp-7019147 (incorrect unit type)	SHAFT (7019147)
383	JLGp-7019160 (incorrect unit type)	Cast Housing Assy (7019160)
384	JLGp-7019878 (incorrect unit type)	Lift Cylinder Seal Kit 7019878 (7019878)
385	JLGp-7020040	SEAL, GREASE
386	JLGp-7020492	SEALING RING
387	JLGp-7021611 (incorrect unit type)	Cartridge 7021611 (7021611)
388	JLGp-7021616 (incorrect unit type)	Cartridge Filter (7021616)
389	JLGp-7022328 (incorrect unit type)	Drive Motor Seal Kit (7022328)
390	JLGp-7022567	COVER
391	JLGp-7022581	KIT, SEAL (BRAKE)
392	JLGp-7022816	SCREW
393	JLGp-7022818	ASSEMBLY, POTENTIOMETER
394	JLGp-7022824	ASSEMBLY, POTENTIOMETER

395	JLGp-7023528 (incorrect unit type)	KIT SEAL 7023528
396	JLGp-7023808	KIT, SEAL
397	JLGp-7023819	KIT, SEAL (MAJOR)
398	JLGp-7023907	KIT, CYLINDER BLOCK
399	JLGp-7023911	CARTRIDGE
400	JLGp-7023914 (incorrect unit type)	Cartridge
401	JLGp-7023919	KIT, SEAL
402	JLGp-7023925	CARTRIDGE
403	JLGp-7023981	CARTRIDGE
404	JLGp-7023983	CARTRIDGE
405	JLGp-7024034	KIT, SEAL
406	JLGp-7024047	KIT, BEARING
407	JLGp-7024056	KIT, SEAL
408	JLGp-7024083	SOLENOID, PROPORTIONAL
409	JLGp-7024100	KIT, SEAL
410	JLGp-7024127	WASHER, THRUST
411	JLGp-7024136 (incorrect unit type)	Hub Seal Kit 7024136 (7024136)
412	JLGp-7024197	KIT, BEARING
413	JLGp-7024389 (incorrect unit type)	Swing Motor Assy.Seal
414	JLGp-7024497 (incorrect unit type)	Cartridge
415	JLGp-7024498	CARTRIDGE
416	JLGp-7024500	CARTRIDGE
417	JLGp-7024508	KIT, SEAL
418	JLGp-7024574 (incorrect unit type)	Valve Seal Kit
419	JLGp-7024713	GEAR, SUN
420	JLGp-7024716	SPACER, INPUT
421	JLGp-7024744 (incorrect unit type)	Seal Kit Hub
422	JLGp-7024749	KIT, INPUT CARRIER
423	JLGp-7024750	KIT, OUTPUT PLANET
424	JLGp-7024765 (incorrect unit type)	KIT, BREAK SEAL
425	JLGp-7024855 (incorrect unit type)	Drive Coil & Cartridge Valve-450Aj 7024855/11005354 (7024855)
426	JLGp-7024856	COIL
427	JLGp-7024857	NUT, SOLENOID VALVE
428	JLGp-7024918 (incorrect unit type)	Seal, Shaft. A076 (7024918)
429	JLGp-7024925 (incorrect unit type)	Valve Assembly
430	JLGp-7026019 (incorrect unit type)	Plug Cavity 7026019 (7026019)
431	JLGp-7026059 (incorrect unit type)	Kit Shim (7026059)
432	JLGp-7026088	HEAD, CYLINDER
433	JLGp-7026096 (incorrect unit type)	Valve Counter Balance
434	JLGp-7026116	KIT, SEAL
435	JLGp-7026189 (incorrect unit type)	Seal 7026189 (7026189)
436	JLGp-7026512 (incorrect unit type)	Seal Kit 7026512 (7026512)
437	JLGp-7026600	STRAINER
438	JLGp-7026665	COUPLING, ROTARY OIL

439	JLGp-7027206	COIL
440	JLGp-7027207	Coil
441	JLGp-7027232 (incorrect unit type)	Coupling Fly Wheel 7027232/7019194 (7027232)
442	JLGp-8180311	CAP RADIATOR 13 PSI
443	JLGp-91414050	KIT, SEAL
444	JLGp-SE0933 (use 1001228326)	Cylinder, Platform Rotation
445	JLGp-0200742	ARM, ADJUSTING
446	JLGp-0440259 (incorrect unit type)	Switch Emergency Stop (4360475)
447	JLGp-0480121	BELT, GENERATOR
448	JLGp-0561471	BLOCK,SPACER
449	JLGp-0610169	P/C Board Platform Display ( Almirah D4 = 02 )
450	JLGp-0641652	SCR CAP HH 5,.375-16X6.500
451	JLGp-0641772	SCR CAP HH 5 .437-14 X 9.00
452	JLGp-0642024	SCR CAP HH 5,.625-11X3.000
453	JLGp-0682014	SCR CAP HH 8,.625-11X1.750
454	JLGp-0682016-012	SCR CAP HH 8,.625-11X2.0-12PCS
455	JLGp-0961894	BUSHING, 1.00 X 2.69
456	JLGp-0961977	BUSHING, 1.00 X1.12 X 1.25BRNZ
457	JLGp-0962122	BUSHING, COMPOSITE 4"
458	JLGp-0962403	BUSHING, BRONZE
459	JLGp-0962450	BUSHING,SPACER
460	JLGp-1001092354 USE 1001121241	SENSOR, SWITCH ANGLE ROTARY USE 1001121241
461	JLGp-1001092454	GAUGE, LCD 5 DIGIT W/ MDI
462	JLGp-1001093626	FILTER,HYDRAULIC
463	JLGp-1001094359	DECAL,TROUBLESHOOTING ES
464	JLGp-1001097347	RELAY,24V SEALED
465	JLGp-1001097551	Coolant Sensor
466	JLGp-1001097893 (incorrect unit type)	Dipstick (1001097893)
467	JLGp-1001099926 (incorrect unit type)	Speed Sensor Kit-Perkins Engine (1001099926)
468	JLGp-1001102811	KIT(SERVICE),TILT SENSOR
469	JLGp-1001109088 (USE 1001284505)	SWITCH, Plunger Limit
470	JLGp-1001109503 (incorrect unit type)	Gauge Indicator
471	JLGp-1001110361	HARNES,MTB
472	JLGp-1001115617 (incorrect unit type)	Seal Kit 1001115617 (1001115617)
473	JLGp-1001118241 (incorrect unit type)	Seal Kit 2902074/1001118241 (1001118241)
474	JLGp-1001118580	SENSOR,SPEED
475	JLGp-1001119262	CONTROL MODULE, JIB
476	JLGp-1001121814	DECAL,WARNING, MAX CAP. DOM.
477	JLGp-1001128737	KIT(SERVICE),BATTERY CHRGR 24V
478	JLGp-1001138827	SENSOR,COOLANT LEVEL

479	JLGp-1001141138	CONTROLLER,PLATFORM WITH LEVEL
480	JLGp-1001141694	CLAMP,AIR CLEANER,POLY
481	JLGp-1001141717	ADPT,SP ST L FNPTF/MPP 6-M16
482	JLGp-1001155213	SEAL,KIT,TELESCOPE
483	JLGp-1001156891	DECAL,MAX TIRE LOAD
484	JLGp-1001159363	CABLE,TRANSPORT SWITCH
485	JLGp-1001159855	DECAL,MAX TIRE LOAD
486	JLGp-1001170847	SENSOR,PROX (M18) (12MM SEN)
487	JLGp-1001182570	SENSOR,PROX (M18)(12MM SEN)
488	JLGp-1001184618	DECAL,STOP & AUX POWER (ANSI)
489	JLGp-1001186467	SENSOR,DUAL AXIS (0XC3)
490	JLGp-1001197240	KIT,860SJ WIRE ROPE KIT
491	JLGp-1001200458	PLATE,LATCH GUIDE
492	JLGp-1001203653	PAD,BOOM REST
493	JLGp-1001211585	PLATE,SENSOR KEYWAY
494	JLGp-1001216060	DECAL,MAX TIRE LOAD
495	JLGp-1001219601	SENSOR,TILT DUAL AXIS CAN
496	JLGp-1001224066	PUMP,MOTOR ASSEMBLY
497	JLGp-1060846	CABLE,MANUAL DESCENT
498	JLGp-1060899	CABLE,SHIELDED .#18/20C 773.43
499	JLGp-1061020	CABLE, EXTENSION CORD (1.5M)
500	JLGp-1061021	CABLE, EXTENSION CORD (3M)
501	JLGp-1061034	CABLE,MANUAL DESCENT (150")
502	JLGp-114370	Decal Sym Tip Over Batt
503	JLGp-1180364	Carrier hose
504	JLGp-1320247	CLAMP,NYLON HOSE/CABLE
505	JLGp-1580012	CONTAINER, STORAGE TRAY
506	JLGp-1600343 (incorrect unit type)	PLATFORM MODULE(1200SJP)-1600343 (1600343)
507	JLGp-1600364 (incorrect unit type)	Ground Module Sftware 4.3-1600364 (1600364)
508	JLGp-1600386	Controller Module
509	JLGp-1600419	CONTROLLER,ES GROUND BOARD
510	JLGp-1660234 (incorrect unit type)	Coupling 8.50 X 1.00 Fly Wheel 500Rts (1660234)
511	JLGp-1670829 (incorrect unit type)	Cover Light housing (1670829)
512	JLGp-1671044	COVER,.12X6.27X9.07 A569
513	JLGp-1671098	COVER, LATCH...
514	JLGp-1683055	CYL,HEAD 1.52 X5.12 X2.50 ALUM
515	JLGp-1683071	Head
516	JLGp-1701504	DECAL, HYD OIL
517	JLGp-1701505	DECAL,DSL
518	JLGp-1701506	DECAL, STEER/AXLE SELECT (FR)
519	JLGp-1701691	DECAL, NO STEP
520	JLGp-1702155	DECAL, BATTERY DISCONNECT
521	JLGp-1703162	DECAL, FAN BLADE
522	JLGp-1703469	DECAL,MAX TIRE LOAD
523	JLGp-1703472 (incorrect unit type)	Decal 1703472/1705171A

524	JLGp-1703482	DECAL,MAX TIRE LOAD
525	JLGp-1703486 (incorrect unit type)	DECAL,MAX TIRE LOAD
526	JLGp-1703804	DECAL,WARNING CRUSHING
527	JLGp-1703805	DECAL, DANGER ELECTROCUTION
528	JLGp-1703822	DECAL,MANUAL DESCENT INSTR
529	JLGp-1703953	DECAL, CRUSH WARNING
530	JLGp-1704277	DECAL,LANYARD ATTACH
531	JLGp-1704412	DECAL, OIL CHART
532	JLGp-1704589	DECAL,GLOW PLUGS
533	JLGp-1705019	DECAL, SAFETY PROP
534	JLGp-1705037	DECAL,CAP(565KG)(DUAL EXT)
535	JLGp-1705084	DECAL,DECIBEL LEVEL
536	JLGp-1705132 (incorrect unit type)	Decal(Control Ade)
537	JLGp-1705170	DECAL,HEADLIGHT
538	JLGp-1705468	DECAL,WARNING DUAL CAPACITY MT
539	JLGp-1705515	DECAL,109DB SOUND POWER LEVEL
540	JLGp-1705667	DECAL,CAPACITY 360 ID 160 OD
541	JLGp-1705686	DECAL,LEGEND (1930ES)
542	JLGp-1705688	DECAL,GROUND CONTROL
543	JLGp-1705693	DECAL,SAFETY PROP
544	JLGp-1705697	DECAL, LED (OVERLOAD)
545	JLGp-1705698	DECAL, CONTROL ICON
546	JLGp-1705752 (incorrect unit type)	DECAL MTB CE 1705752
547	JLGp-1705913	DECAL, PLATFROM DISPLAY
548	JLGp-1705914	DECAL, PLATFORM BOX
549	JLGp-1706350	DECAL, COVER
550	JLGp-1706741	DECAL,BOOM CONTROL SELECT
551	JLGp-1706920	DECAL, MTB
552	JLGp-1706921	DECAL, MTB
553	JLGp-1706945	DECAL, MTB
554	JLGp-2120217	FILTER,HIGH PRESSURE
555	JLGp-2120219	FILTER,ELEMENT FOR 2120218
556	JLGp-2420199	GAUGE, FUEL LEVEL (IBEX)
557	JLGp-2420203	GAUGE,VOLTMETER
558	JLGp-2460049	GENERATOR, 110V 50HZ
559	JLGp-2600246	HINGE,CONCEALED LIFT OFF
560	JLGp-2600286	HINGE, HOOD MOUNT
561	JLGp-2760105 (incorrect unit type)	Housing Display Light
562	JLGp-2901271 (incorrect unit type)	Axle Lockout Cylinder Seal Kit (2901271)
563	JLGp-2901547 (incorrect unit type)	STEER CYLINDER SEAL KIT 2901547
564	JLGp-2901549 (incorrect unit type)	Levelling Cylinder Seal Kit 2901549 (2901549)
565	JLGp-2901776 (incorrect unit type)	Seal Kit 2901776 (2901776)
566	JLGp-2901810 (incorrect unit type)	Jib Cylinder Seal Kit 2901810 (2901810)
567	JLGp-2901901	KIT,SEAL 3 X 1.5 CAPPED "T"
568	JLGp-2902044 (incorrect unit type)	Tower Boom Cylinder Seal (2902044)

569	JLGp-2902073 (incorrect unit type)	Seal Kit 2902073 (2902073)
570	JLGp-2902082	KIT, SEAL 1350 LIFT CYL
571	JLGp-2902291	KIT, SEAL
572	JLGp-2902498	KIT, DECAL MULTI COLOR (CE)
573	JLGp-2940073	LATCH,(1/4 TURN LOCK)
574	JLGp-2940126	LATCH, ROTARY PADDLE
575	JLGp-2940135 (incorrect unit type)	Latch
576	JLGp-2940174	LATCH,T-HANDLE
577	JLGp-3272001	NUT HEX,.625-11 GR 8
578	JLGp-3272401	NUT HEX LOCK,.875- 9 GR 8
579	JLGp-3300007	Nut
580	JLGp-3300240	NUT-SPEC, LOCK .625
581	JLGp-3300241	NUT-SPEC, LOCK .750 NYLON
582	JLGp-3300399	NUT- SPEC, 7/8-9
583	JLGp-3312005	NUT HEX,.625-11 LOCK
584	JLGp-3340757	PAD, .75 X 7.25 X 9.00 UHMW
585	JLGp-3340764	PAD, 2.00 X 2.25 X 5.12 UHMW
586	JLGp-3340787	PAD, .75 X 3.00 X 7.38 UHMW
587	JLGp-3340871	PAD,WEAR .75X2.50X8.00 UHMW
588	JLGp-3340907	Pad, 75x6.00x6.00UHMW
589	JLGp-3340912	PAD, ASSEMBLY WEAR
590	JLGp-3340916	PAD,ASSEMBLY WEAR
591	JLGp-3340921	PAD, ASSEMBLY WEAR
592	JLGp-3340922	PAD, ASSEMBLY WEAR
593	JLGp-3340929	PAD,ARM (.750)
594	JLGp-3340932	Wear Pad 62 X 4 X 8
595	JLGp-3340935	PAD,SLIDE 1.00X4.50X8.50 UHMW
596	JLGp-3340943 (incorrect unit type)	Pad Rubber (3340943)
597	JLGp-3340968	PAD, MEMBRANE SWITCH
598	JLGp-3422568	PIN, 2.00 X 12.75 1045
599	JLGp-3422592 (incorrect unit type)	Pin, Axle Pivot 2.00X10.19
600	JLGp-3422703 (incorrect unit type)	Main Pivot Pin(2713) (3422703)
601	JLGp-3422754	PIN,STEER AXLE ATTACH
602	JLGp-3422792 (incorrect unit type)	Pin 3422792 (3422792)
603	JLGp-3422938	PIN, OVERLOAD, 1.25 DIA.
604	JLGp-3422944	PIN,ARM PIVOT 130K
605	JLGp-3422945	PIN,ARM PIVOT
606	JLGp-3422959	PIN,1.50X7.06
607	JLGp-3422966	PIN,EXTENSION ROLLER
608	JLGp-3422972 (incorrect unit type)	King Pin 3422972 (3422972)
609	JLGp-3580134	PULLEY, SINGLE GROOVE
610	JLGp-3580300	PULLEY,FLY EXT ASSY
611	JLGp-3841406S	ROD,WELDMENT
612	JLGp-3841469	ROD, .63X1.50X3.38
613	JLGp-3890008	ROPE, WIRE RETRACT 230.625 LG

614	JLGp-3900223 (incorrect unit type)	Screw shoulder
615	JLGp-3900283	SCREW-SPEC,3/8 BUTTON HEAD
616	JLGp-3931508	SCR CAP SOC HD .31-18 X .500
617	JLGp-4000008	SENSOR, PROXIMITY ASSY
618	JLGp-4071035	SHIM,.05X6.00X8.00
619	JLGp-4071039	SHIM,.05X4.00X8.38
620	JLGp-4071040	SHIM,.12X4.00X8.38
621	JLGp-4360401	SWITCH, ROLLER PLUNGER HD
622	JLGp-4360436	SWITCH, FUEL LEVEL
623	JLGp-4360437	SWITCH, (LIMIT)
624	JLGp-4360462 (incorrect unit type)	SWITCH, POTENTIOMETER
625	JLGp-4360483	SWITCH, TOGGLE
626	JLGp-4360506 (incorrect unit type)	SWITCH,PROXIMITY (4360506)
627	JLGp-4360524S	SWITCH, 3 POSITION SPRING RETU
628	JLGp-4360538	SWITCH, MEMBRANE
629	JLGp-4460420	TERMINAL,SLIP-ON
630	JLGp-4460466	TERMINAL,SEALING PLUG
631	JLGp-4460471	TERMINAL, RECEPTACLE LOCKWASH
632	JLGp-4460536	CONNECTOR,3 PIN FEMALE
633	JLGp-4460741	TERMINAL,PLUG FOR BOSCH TYPE R
634	JLGp-4460812	TERMINAL, CONN PLUG 16-24
635	JLGp-4460836	TERMINAL, CONN 12 POS
636	JLGp-4460866 (incorrect unit type)	Terminal,Conn Recept 19Pin Female (4460866)
637	JLGp-4460875	TERMINAL, CONN 35 POS GRAY
638	JLGp-4460876	TERMINAL, CONN BLUE
639	JLGp-4460892 (incorrect unit type)	Terminal Host Pushbar (4460892)
640	JLGp-4461008	TERMINAL,HOLE PLUG
641	JLGp-4461012	Terminal, Conn 12V Recpt
642	JLGp-4461052	TERMINAL,25 POS SPLASH PROOF C
643	JLGp-4461054	TERMINAL,WIRE SEAL
644	JLGp-4461060	TERMINAL,PIN 25 OS CONN
645	JLGp-4461070 (incorrect unit type)	Terminal,Connector 3Pos (4461070)
646	JLGp-4640816	VALVE, VENT C
647	JLGp-4640858	VALVE, BLEEDER .38 X 1.17
648	JLGp-4640871 (incorrect unit type)	Lockout Valve Assy (Swing break Repair Kit)
649	JLGp-4640929	VALVE, (DIR ACT RELIEF)
650	JLGp-4640999	VALVE,NON VENTED C/BAL
651	JLGp-4641162 (incorrect unit type)	Valve,C Balance(Was P/N 4640525) (4641162)
652	JLGp-4641188 (incorrect unit type)	Cartridge,Lift Holding Valve (4641188)
653	JLGp-4641205	VALVE,PULL MAN.DESC.
654	JLGp-4641234 (incorrect unit type)	Cartridge Valve
655	JLGp-4641285	VALVE, SHUTTLE
656	JLGp-4740505	WASHER, THRUST
657	JLGp-4740541	WASHER-SPEC,THRUST, .0625
658	JLGp-4922762	HARNES,18/3 CONTROL 1350SJP

659	JLGp-4922869	HARNESS, EIM LOADCELL
660	JLGp-4922882	HARNESS, OVERLOAD (RT)
661	JLGp-4922947	HARNESS,RIGHT LEVEL SENSOR
662	JLGp-4922948	HARNESS,LEFT LEVEL SENSOR
663	JLGp-4922955	WIRE,MAIN BOOM CONTROL HARNESS
664	JLGp-4923170	HARNESS, DUAL CAPACITY
665	JLGp-4923171	HARNESS, TRANSPORT LENGTH
666	JLGp-4923260	HARNESS, ENGINE (DEUTZ)
667	JLGp-7000082	MICROSWITCH, BH HANDLE
668	JLGp-7000803	SWITCH, PRESSURE
669	JLGp-7000811	O-RING, DISCONNECT CAP
670	JLGp-7000817	O-RING, COVER
671	JLGp-7000819	KIT, SHAFT
672	JLGp-7000832	SEAL
673	JLGp-7000842	RING, BACKUP
674	JLGp-7000843	O-RING
675	JLGp-7000844	O-RING
676	JLGp-7000845	RING, BACKUP
677	JLGp-7000850	O-RING
678	JLGp-7000917	SEAL, FUEL SUPPLY PUMP
679	JLGp-7000945	KIT, SEAL
680	JLGp-70001396	PUMP, WATER
681	JLGp-70001499	KIT, SEAL
682	JLGp-70002013	KIT, 2' REPAIR SECTION
683	JLGp-70002147	VALVE, SOLENOID (12 VOLT)
684	JLGp-70002225 (incorrect unit type)	Kit Seal (70002225)
685	JLGp-7000231	DISCONNECT CAP
686	JLGp-7000265 (incorrect unit type)	Stud-7000265 (7000265)
687	JLGp-70002727	ASSEMBLY, HANDLE
688	JLGp-70003614	KIT, HYDRAULIC FILTER
689	JLGp-70003859 (incorrect unit type)	Seal Kit 70003859 (70003859)
690	JLGp-7000418	SOLENOID COIL
691	JLGp-70004407	O-RING
692	JLGp-70004451	KIT, SEAL
693	JLGp-70004516	RING, SEALING
694	JLGp-70005722	CARTRIDGE, HAND PUMP
695	JLGp-70006115	CARTRIDGE, DIRECTIONAL CONTROL
696	JLGp-7001625 (incorrect unit type)	Seal Kit
697	JLGp-70024493	GASKET
698	JLGp-70024513	SENSOR CABLE
699	JLGp-70024918	TEMP SENSOR, COOLANT
700	JLGp-70025076	VALVE
701	JLGp-70025713	USE 70005497 - SEAL
702	JLGp-70025780	RELAY
703	JLGp-7002823 (incorrect unit type)	Wire Pin Extractor (7002823)



704	JLGp-7003935 (incorrect unit type)	SLAVE GEAR (7003935)
705	JLGp-7003946 (incorrect unit type)	ETURN SPRING (7003946)
706	JLGp-7003977 (incorrect unit type)	Gear Drive (7003977)
707	JLGp-7003980	SCREW, 3 X 12
708	JLGp-7010406	LIP SEAL
709	JLGp-7010494	Plug Pipe
710	JLGp-7010640	SPRING 8-REQ
711	JLGp-7011112	KIT, SEAL
712	JLGp-7011355 (incorrect unit type)	Valve, Shuttle P74165/7011355 (7011355)
713	JLGp-7011907	ELECTRICAL ASSY
714	JLGp-7012693 (incorrect unit type)	Kit Seal 7012693 (7012693)
715	JLGp-7012694	CARTRIDGE,HAND PUMP
716	JLGp-7012773 (incorrect unit type)	Cartridge Valve Seal Kit (7012773)
717	JLGp-7012944 (incorrect unit type)	Coil-12Vdc Hydraforce(6306012) (7012944)
718	JLGp-7012955	VALVE, CHECK
719	JLGp-7012959 (incorrect unit type)	Knob (7012959)
720	JLGp-7014709	KIT, RETAINING RING
721	JLGp-7017068 (incorrect unit type)	Hub Seal Kit 7017068 (7017068)
722	JLGp-7017072 (incorrect unit type)	Pipe Plug (7017072)
723	JLGp-7017092 (incorrect unit type)	Pin Dowel
724	JLGp-7017093 (incorrect unit type)	Cap Disconnect
725	JLGp-7017190	Valve, motion control - 70001639
726	JLGp-7017213	GUIDE 3.00 X 1.50
727	JLGp-7017290 (incorrect unit type)	Steer Cylinder Seal Kit 7017290 (7017290)
728	JLGp-7017410 (incorrect unit type)	Cartridge valve
729	JLGp-7017422 (incorrect unit type)	Cartridge valve
730	JLGp-7017428	CARTRIDGE
731	JLGp-7017451 (incorrect unit type)	Coil Of 4641234 7017451 (7017451)
732	JLGp-7017496	KIT, SEAL
733	JLGp-7018564 (incorrect unit type)	Relay 7018564 (7018564)
734	JLGp-7018589	VARISTOR
735	JLGp-7019111	BEARING, GEARHEAD
736	JLGp-7019143	SCREW
737	JLGp-7019147 (incorrect unit type)	SHAFT (7019147)
738	JLGp-7019149	SETSCREW
739	JLGp-7019155 (incorrect unit type)	Shaft 8Mm (7019155)
740	JLGp-7019160 (incorrect unit type)	Cast Housing Assy (7019160)
741	JLGp-7019167	NUT
742	JLGp-7019177	SHAFT, CAM
743	JLGp-7019300	LINK, REPLACEMENT
744	JLGp-7019878 (incorrect unit type)	Lift Cylinder Seal Kit 7019878 (7019878)
745	JLGp-7020461	SWITCH
746	JLGp-7020500 (incorrect unit type)	Micro Switch 7020500 (7020500)
747	JLGp-7020520	BOOT W/2" FLANGE & GASKET
748	JLGp-7020529	ASSEMBLY, HANDLE

749	JLGp-7020556	BOOT, RUBBER
750	JLGp-7020651	SHUNT ASSY, REPLACEMENT
751	JLGp-7020653	CIRCUIT BREAKER, 10AMP AC
752	JLGp-7020654 (incorrect unit type)	Relay 24Vdc-30A (7020654)
753	JLGp-7020691	FUSE, AUTOMOTIVE 80V 50A
754	JLGp-7021232	KIT, SEAL
755	JLGp-7021611 (incorrect unit type)	Cartridge 7021611 (7021611)
756	JLGp-7021636 (incorrect unit type)	Cartridge
757	JLGp-7022314	RETAINER, SPRING
758	JLGp-7022373 (incorrect unit type)	Drive Coil (7022373)
759	JLGp-7022581	KIT, SEAL (BRAKE)
760	JLGp-7022601	VALVE, RELIEF
761	JLGp-7022655	VALVE, FILL
762	JLGp-7022808 (USE JLGp-70004768)	CAP, LIFT
763	JLGp-7022816	SCREW
764	JLGp-7022903 (incorrect unit type)	Control Ac 1-48V (7022903)
765	JLGp-7022925	CIRCUIT, CONTROL
766	JLGp-7023173 (incorrect unit type)	Sensor Speed (7023173)
767	JLGp-7023209	Seal Kit
768	JLGp-7023536	VALVE, DIRECTIONAL CONTROL
769	JLGp-7023537	VALVE, DIRECTIONAL CONTROL
770	JLGp-7023538	VALVE, CHECK
771	JLGp-7023559 (incorrect unit type)	Seal Kit Steering Cyl.
772	JLGp-7023911	CARTRIDGE
773	JLGp-7023914 (incorrect unit type)	Cartridge
774	JLGp-7023915 (incorrect unit type)	Cartridge
775	JLGp-7023919	KIT, SEAL
776	JLGp-7023948 (incorrect unit type)	KIT, SWASHPLATE BEARING
777	JLGp-7023983	CARTRIDGE
778	JLGp-7024005	PLATE, WEAR
779	JLGp-7024031	O-RING
780	JLGp-7024032	O-RING
781	JLGp-7024034	KIT, SEAL
782	JLGp-7024048	RING, SEAL
783	JLGp-7024071	O-RING
784	JLGp-7024072	O-RING
785	JLGp-7024075	O-RING
786	JLGp-7024076	RING, BACK-UP
787	JLGp-7024077	O-RING
788	JLGp-7024193	KIT, FRICTION DISC
789	JLGp-7024194 (incorrect unit type)	Brake Seal Kit
790	JLGp-7024197	KIT, BEARING
791	JLGp-7024362	KIT, 24" REPAIR SECTION
792	JLGp-7024364	KIT, ROLLER ASSEMBLY
793	JLGp-7024506	KIT, COIL NUT

794	JLGp-7024565 (incorrect unit type)	Speed Sensor 7024565 (7024565)
795	JLGp-7024571 (incorrect unit type)	Coil 7024571 (7024571)
796	JLGp-7024574 (incorrect unit type)	Valve Seal Kit
797	JLGp-7024720	KIT, SEAL
798	JLGp-7024738	RING, RETAINING
799	JLGp-7024744 (incorrect unit type)	Seal Kit Hub
800	JLGp-7024764 (incorrect unit type)	Kit, Brake Lining
801	JLGp-7024855 (incorrect unit type)	Drive Coil & Cartridge Valve-450Aj 7024855/11005354 (7024855)
802	JLGp-7024856	COIL
803	JLGp-7024919	O-RING
804	JLGp-7024920	O-RING
805	JLGp-7024921	SEAL
806	JLGp-7024922	O-RING
807	JLGp-7024962 (incorrect unit type)	Seal Kit
808	JLGp-7024966	O-RING
809	JLGp-7024968	SEAL, FACE
810	JLGp-7024971	Bearing ball torque hub 1350 Rexorth
811	JLGp-7024972	O-RING
812	JLGp-7024974	O-RING
813	JLGp-7024976	KIT, BRAKE DISC
814	JLGp-7026072 (incorrect unit type)	SEAL KIT
815	JLGp-7026080 (incorrect unit type)	Main Boom Seal Kit
816	JLGp-7026087	KIT, SEAL (CYLINDER)
817	JLGp-7026096 (incorrect unit type)	Valve Counter Balance
818	JLGp-7026103 (incorrect unit type)	Seal Kit 7026103 (7026103)
819	JLGp-7026107 (incorrect unit type)	STEER CYLINDER SEAL KIT-450A
820	JLGp-7026116	KIT, SEAL
821	JLGp-7026189 (incorrect unit type)	Seal 7026189 (7026189)
822	JLGp-7026512 (incorrect unit type)	Seal Kit 7026512 (7026512)
823	JLGp-7026680	Kit, Tie rod o-ring
824	JLGp-7026692	VALVE, SOLENOID USE 70007939
825	JLGp-7026885	DIPSTICK
826	JLGp-7027367	PUSHBUTTON, MOMENTARY (BLACK)
827	JLGp-7028848	KIT, SECTIONAL SEAL ...
828	JLGp-79925713	Seal can use 70005497
829	JLGp-8007935	S/K, VALVE SECTION
830	JLGp-8007954	S/K,INTERFACE-ACT.TO MAIN BDY
831	JLGp-80434249	COIL, 12V
832	JLGp-E900025	CONTROLLER, JOYSTICK
833	JLGp-E900030	DECAL, CONSOLE
834	BOSp-0001109035	Starter Motor Perkins
835	CUMp-393090600	Valve Cover Gasket 6 BTA5-9-G5
836	CUMp-395791200	Seal,Valve stem
837	DEUp-0118-0967	Engine Dipstick-Deutz

838	DEUp-0427-2545	Fly Wheel Ring Gear, 0410-2124, 0427-2421
839	GENp-101277GT	VALVE.RELIEF.2100 PSI***)
840	GENp-101920GT	GUIDE.ALUMINUM EXTRUSION)
841	GENp-101921GT	GUIDE.ALUMINUM EXTRUSION)
842	GENp-104940GT	HARNES,LOAD SENSE,EXTENSION
843	GENp-105109GT	TURN SWITCH ACTUATOR.JOYSTICK**)
844	GENp-105115GT	KIT.JOYSTICK STEER SWITCH)
845	GENp-105171GT	KIT.JOYSTICK ENABLE SWITCH)
846	GENp-105193GT	CLIP.CABLEBRIDGE.GS32/46)
847	GENp-105548GT	KIT,MINI LIFT CYL SEAL
848	GENp-106125GT	SEAL KIT, BRAKE, 4HP
849	GENp-106532GT	Seal Kit
850	GENp-106843GT	U-BOLT.1/4-20.SQUARE 3.5X3.5)
851	GENp-107717GT	ASSY,FOUR LINK CABLE TRACK***
852	GENp-107752GT	Valve Proportional (S85)
853	GENp-107816GT	VALVE,PROPORTIONAL 3 POS 4 WY*
854	GENp-107830GT	Subassy, Steer sensor
855	GENp-111778GT	COIL.10V DC
856	GENp-112543GT	entry gate latch Genie 5390/71271
857	GENp-121650GT	Injection, 10 Degree Limit Cam
858	GENp-1255271GT	SEAL KIT (823060)
859	GENp-1256679GT	Nut
860	GENp-1256725GT	Pcba, Pcon Std, Prop Lift GN1256725 (GN1256725)
861	GENp-1261835GT	Screw
862	GENp-1262407GT	WELDMENT. PIN. 1.75DIA X 4.375LG)
863	GENp-1268809GT	Coupler, Splined, 9tooth, 300 long - GS3246
864	GENp-1270697GT	Pump, Gear 3369RT
865	GENp-1274322GT	NUT,NYLOCK FLG,3/8-16,F,ZAG
866	GENp-1278840GT	Kit Timing link cam
867	GENp-128203GT	Toggle Switch, 128203GT
868	GENp-133205GT	Decal, Label Electro Hazard
869	GENp-137692GT	GCON, GR/GRC/GS
870	GENp-139598GT	BOOT,JOYSTICK
871	GENp-139832GT	Primary Up & down Limit switch S65
872	GENp-146058GT	Seal kit (89534) Level Cylinder S-105
873	GENp-146059GT	Seal Kit (121140)
874	GENp-146060GT	Seal Kit, Master Cylinder (121236) S-85
875	GENp-148389GT	Guage Fuel
876	GENp-19506GT	HOUR METER, 10-80 VOLTS***
877	GENp-21142GT	Seal Kit (W1B) Torque Hubs
878	GENp-22446GT	SPRING-CHOKE RETURN.
879	GENp-226802GT	GAS SPRING.20LB.12 EXTENDED)
880	GENp-227515GT	Foot Switch Assy, Genie S-105, 120, 125 & Z-135
881	GENp-229086GT	FIXING SCREWS
882	GENp-25284GT	ROD END,.375 X 2.25***

883	GENp-28161GT	DECAL.WARN.CRUSH HAZARD HAND)
884	GENp-29764GT	NUT.NYLOCK.1-8)
885	GENp-30810GT	SWITCH PRESSURE
886	GENp-32675GT	SEAL KIT,SUNSTRAND
887	GENp-35974GT	SCREW.HHC.1-8 X 7 GRD.2)
888	GENp-36388GT	Bumper, rubber S85
889	GENp-39346GT	Valve Solenoid 12V Solenoid Valve 3Pos,4Way(Sv08-4745D) (GN3
890	GENp-43179GT	Fuse 500 Amp, Very Fast Acting / 45Z
891	GENp-44168GT	VALVE.SOLENOID.3POS 4WAY)
892	GENp-44174GT	Nut-Coil Short (S65)
893	GENp-44178GT	VALVE.CHECK.5 PSI**)
894	GENp-44216GT	VALVE,SHUTTLE
895	GENp-44225GT	SEAL KIT. VALVE)
896	GENp-45209GT	Wear Pad 4x2x.5 w/insert
897	GENp-45495GT	Screw, SHC, 5/8-11 x 3.00 A574
898	GENp-47092GT	ORIFICE DISC..046.GREEN)
899	GENp-48647GT	VALVE.COUNTERBALANCE.3500 PSI*)
900	GENp-50481GT	VALVE.COUNTERBALANCE.3500 PSI)
901	GENp-52464GT	BREATHER CAP ASSEMBLY. GS68)
902	GENp-52906GT	VALVE-RELIEF.3200 PSI)
903	GENp-54432GT	Lanyard Lynch Pin Assy
904	GENp-55185GT	Bearing FLG-2.25X1.75X0.75
905	GENp-55484GT	RETAINER, GS68 O/R FOOTPAD***
906	GENp-56680GT	SCREW.SHC.1/2-13 X 4.50 ZINC)
907	GENp-58566GT	Filter Head
908	GENp-60313GT	CABLE TRACK.STEEL 60 LINKS**)
909	GENp-60693GT	SPRING.URETHANE.1 ID X 2.00 LG)
910	GENp-60745GT	Shim, Galvanized Steer Yoke
911	GENp-61203-SGT	PLATE.URETHANE SPRING)
912	GENp-61304GT	Shim-Genie S125/122248
913	GENp-61305GT	Shim-Genie S125/122249
914	GENp-61307GT	Shim, Inner Axle Wear Pad
915	GENp-61310-SGT	Plate, Axle Wear Steel
916	GENp-61591-SGT	WELDMENT.URETHANE SPRING CUP)
917	GENp-62320GT	Repair Link/Single-Genie S125
918	GENp-62322GT	Repair Link Set ( 60313 ) 4 Link
919	GENp-62323GT	VALVE.DIFFERENTIAL SENSE110PSI)
920	GENp-62346GT	Valve-Flow Regulator-2.0 Gpm Gn62346 (Gn62346)
921	GENp-62815GT	VALVE,SOLENOID,2POS 3 WAY***
922	GENp-63348GT	Seal Kit, Cylinder
923	GENp-65061GT	Cosmetic Genie
924	GENp-6564GT	Shim Washer
925	GENp-66813GT	Button , Push Black W/Seal
926	GENp-72816GT	DECAL,NOTICE,MAX CAP,1500 LBS

927	GENp-75116GT	SEAL KIT.TURNTABL.ROT.MOTOR*)
928	GENp-77246GT	SEAL KIT,SWING MOTOR***
929	GENp-77410GT	Valve, Counterbalance, 1500PSI
930	GENp-77515GT	SEAL KIT.PRIM LIFT CYL
931	GENp-78674GT	LEVEL SENSOR,LS60,BLUE,2X3**
932	GENp-79355GT	PLUG.TUBE.SQ 1.50X.065)
933	GENp-82238GT	Decal,PlatformControl Panel - ALM - C1-03
934	GENp-82366GT	DECAL. LABEL - CHEVRON RANDO)
935	GENp-824030GT	NUT. TL FLG. 3/4-10. G. ZAG)
936	GENp-824051GT	SEAL KIT,SWING DRIVE
937	GENp-82418GT	Label Ground Control Panel
938	GENp-826779GT	Valve, Shuttle
939	GENp-82824GT	DECAL
940	GENp-84108GT	VALVE,PROP,N.C.,PRIORITY STYLE
941	GENp-84109GT	VALVE,DIR,#10 SAE,3POS
942	GENp-8638GT	toggle switch
943	GENp-87296GT	Seal Kit Steer Cylinder
944	GENp-88096PGT	Forming Retract Limit Swith
945	GENp-94203GT	Seal Kit, 94203GT (Jib Cylinder)
946	GENp-94616GT	Valve 160PSI GN94616 (GN94616)
947	GENp-94980GT	Sensor, Dual Output Angle
948	GENp-96309GT	POTHOLE HARNESS ASSEMBLY
949	GENp-97373GT	SPACER.COIL)
950	GENp-T107366GT	ASSY.LIM.SW.ACTUATOR BLOCK)
951	GENp-T112457GT	DIESEL CAP GS3369
952	GN824027	Nut TL FLG 1/4-20
953	HATp-01806400	Injection Pump-Hollandlift,Hatz Engine
954	HOLp-103693	Battery PLC Control
955	HOLp-103728	Manifold-HL 320
956	HOLp-104367 ( LEVEL010)	Tilt Sensor-Holland Lift
957	HOLp-106682	drive motor G320
958	HOLp-107221	pressure sensor holland lift
959	HOLp-108645	locking disk HL G320
960	HOLp-50548400	Nozzle - Hollandlift,Hatz Engine
961	JLGp-0060091	ACTUATOR,POTHOLE WELD
962	JLGp-0140028	ALARM, (HORN)
963	JLGp-0140030	ALARM,
964	JLGp-0440135	BEARING, SLEEVE 2.00X2.25X .75
965	JLGp-05120200	HYDRAULIC OIL FILTER
966	JLGp-0641648	SCR CAP HH 5,.375-16X6.000
967	JLGp-0641812	SCR CAP HH 5,.500-13X1.500
968	JLGp-0682212	HEX HD CAP SCR 3/4-10X1 1/2 LG
969	JLGp-0811616	SCREW,HEX FLANGE GR8 3/8X2.0LG
970	JLGp-0840055	BOOT, 12 POSITION DT SERIES DE
971	JLGp-0902414	BRKT,WELDMENT ROTATOR

972	JLGp-0902874	BRKT,LATCH PAWL
973	JLGp-0920118	BRAKE, MULTI-DISC
974	JLGp-0960564	BUSHING, 2.51X 2.00 X 3.00 BRZ
975	JLGp-0961893	BUSHING, 1.00 X 2.00 X 1.00
976	JLGp-0961948	BUSHING, COMPOSITE 1 1/2"
977	JLGp-0961977	BUSHING, 1.00 X1.12 X 1.25BRNZ
978	JLGp-0962005	BUSHING, 1.00 X1.12 X 1.50PTFE
979	JLGp-0962292	BUSHING,1"ID X 3/4" LONG GARMA
980	JLGp-0962406	BUSHING,COMPOSITE 2.5"
981	JLGp-0962411	BUSHING,COMPOSITE 2.5 IN
982	JLGp-0962496	BUSHING, 1.25" COMPOSITE
983	JLGp-1001091731	Ground module controller, RT model, 1001135570
984	JLGp-1001092405	HOLDER,FUSE
985	JLGp-1001092497	DECAL,NO PIPE RACK ALLOWED
986	JLGp-1001101233	HOSE,RADIATOR TOP
987	JLGp-1001114936	Tilt Sensor
988	JLGp-1001118241	SEAL,KIT
989	JLGp-1001118419	Controller,Lift Swing
990	JLGp-1001120098	CABLE, CONTROL 1060896 36' JIB
991	JLGp-1001120278	HARNESS,BOOM CYL ANGLE
992	JLGp-1001129285	FUSE,MINI DIODE
993	JLGp-1001135924	PIPE,RAD UP
994	JLGp-1001143434	CYL,STEER
995	JLGp-1001161403	PAD,AXLE SIDE
996	JLGp-1001163767	CYL,JIB ASSY
997	JLGp-1001164585	KIT(SERVICE),SEAL
998	JLGp-1001169183	HOOD,450AJ FRONT
999	JLGp-1001169611	PAD,POWER TRACK
1000	JLGp-1001170446	DECAL,PLATFORM DISPLAY
1001	JLGp-1001170838	LAMP, PANEL LED PCB ASSY
1002	JLGp-1001174326	KIT(SERVICE),SEAL
1003	JLGp-1001175887	SEAL,KIT
1004	JLGp-1001178139	CONTROL,CONTROL,LIFT/SWING
1005	JLGp-1001188843-	SEAL,KIT CYL
1006	JLGp-1001189223	KIT(SERVICE),JIB ANGLE SENSOR
1007	JLGp-1001200848	SENSOR,ANGLE
1008	JLGp-1061034	CABLE,MANUAL DESCENT (150")
1009	JLGp-1600352	CONTROLLER, JOYSTICK P/Q150HAX
1010	JLGp-1682534	CYL, ROD WELDMT
1011	JLGp-1683059	CYL,HEAD 1.52 X5.62 X2.50 ALUM
1012	JLGp-1683759	CYL,LEVEL ROD WELDMENT, 300A
1013	JLGp-1683961	CYL,ROD WELD
1014	JLGp-1684126	CYL, ROD WELDMENT
1015	JLGp-1684176S	Cyl. Rod Weldment
1016	JLGp-1701524	DECAL, SAFETY PROP (IT)

1017	JLGp-1704460	DECAL,DRIVE & STEER
1018	JLGp-1704574	DECAL,OUTRIGGER SELECT
1019	JLGp-1704588	DECAL,FUEL SELECT
1020	JLGp-1705037	DECAL,CAP(565KG)(DUAL EXT)
1021	JLGp-1705038	DECAL,MODEL(3394RT)
1022	JLGp-1705042	DECAL,MAX LOAD (JACKS)
1023	JLGp-1705084	DECAL,DECIBEL LEVEL
1024	JLGp-1705212	DECAL,LIGHT DISPLAY (CE)
1025	JLGp-1705460	DECAL,SKY POWER
1026	JLGp-1705912	DECAL, PLATFORM BOX
1027	JLGp-2120219	FILTER,ELEMENT FOR 2120218
1028	JLGp-2220373	ADPT,ST S JIC/ORB 8-8 FG
1029	JLGp-2420172	GAUGE, HOURMETER
1030	JLGp-2440043	GEAR, WORM
1031	JLGp-2440044	GEAR, WORM
1032	JLGp-2558640012	FUEL TANK CAP
1033	JLGp-2560176	HANDLE,GRAB
1034	JLGp-2600253	HINGE,.94X2.75X2.94
1035	JLGp-2600285	HINGE,SELF CLOSING
1036	JLGp-2646170010	LEVER
1037	JLGp-2646170027	BEEPER REMOTE CONTROL
1038	JLGp-26608200L	ELECTRONIC BOARD
1039	JLGp-2680497	HOOD,TANK SIDE FRONT
1040	JLGp-27005200	DECALS KIT
1041	JLGp-2720333	HOSE, RADIATOR 1.75"
1042	JLGp-2720371	HOSE, RADIATOR
1043	JLGp-2760064	HOUSING, GEAR
1044	JLGp-2900477	KIT, SEAL
1045	JLGp-2900733	SEAL KIT-MOTOR
1046	JLGp-2900766	SEAL,KIT 0920081
1047	JLGp-2901103	KIT,SEAL
1048	JLGp-2901147	SEAL,KIT
1049	JLGp-2901148	SEAL,KIT
1050	JLGp-2901322	KIT,SEAL
1051	JLGp-2901461	KIT,SEAL
1052	JLGp-2901547	KIT, SEAL
1053	JLGp-2901805	KIT,SEAL
1054	JLGp-2901807	KIT,SEAL
1055	JLGp-2901810	KIT,SEAL
1056	JLGp-2901903	KIT,SEAL
1057	JLGp-2902044	KIT, SEAL
1058	JLGp-2902284	KIT, SEAL
1059	JLGp-2902409	KIT,SEAL
1060	JLGp-2940042S	LATCH,FLUSH MT./SERVICE ONLY
1061	JLGp-2940113	LATCH, LIFT & TURN FLUSH MT



1062	JLGp-2940117	LATCH,HOOD 300AE
1063	JLGp-2940135	LATCH, SLAM, ROTARY PADDLE
1064	JLGp-2940173	LATCH,ROTARY
1065	JLGp-2940174	LATCH,T-HANDLE
1066	JLGp-3200183	MOUNT, ENG. RESILIENT
1067	JLGp-3220079	MUFFLER,
1068	JLGp-3252378	NAMEPLATE, CONSOLE LID (CE)
1069	JLGp-3300007-006	NUT-SPEC,T .750-16 WHEEL-QTY=6
1070	JLGp-3300106	NUT-SPEC, HX 5/8-18 WHEEL
1071	JLGp-3312002	NUT HEX,.625-11 LOW HT
1072	JLGp-3340453	PAD, .50 X 1.75 X 8.00 NYLTN
1073	JLGp-3340454	PAD, .25 X 1.31 X 4.88 BK-LN
1074	JLGp-3340595	PAD, WEAR - DRIVE AXLE
1075	JLGp-3340596	PAD, WEAR - STEER AXLE
1076	JLGp-3340837	PAD,2.50X6300X.75 UHMW
1077	JLGp-3340881	PAD,WEAR .62X2.50X6.00 UHMW
1078	JLGp-3340900	PAD,WEAR.75X4.50X9.38 UHMW GRN
1079	JLGp-3340907	Pad, 75x6.00x6.00UHMW
1080	JLGp-3340925	PAD,PUSH TUBE
1081	JLGp-3340927	PAD,BOOM REST
1082	JLGp-3380434S	Panel,Molded-860SJ
1083	JLGp-3422860	PIN,EAR TOP BOOM 1.00X9.44
1084	JLGp-3423259	PIN,ARM PIVOT (SENSOR)
1085	JLGp-3450806	pin, cotter
1086	JLGp-3480267	PISTON, CYL
1087	JLGp-3572950	PLATE, RET. SHEAVE
1088	JLGp-3600289	ELECTRIC MOTOR PUMP ASSY.
1089	JLGp-3740063	RELAY, SPRING
1090	JLGp-3760368	RING, 3.00 X 4.25 X .12 A607
1091	JLGp-3760369	RING, 3.50 X 5.00 X .12 A607
1092	JLGp-3841013 (USE JLGp-3841013S)	roller, rod USE JLGp-3841013S
1093	JLGp-3841258	ROD, .62 X .69 X 4.50 4140
1094	JLGp-3860059	ROLLER, EXT 3.06 X 1.12 POLY
1095	JLGp-3900259	SCREW,SOULDER
1096	JLGp-3931448	SCR CAP SOC HD .25-20 X 3.000
1097	JLGp-3931620	SCR CAP SOC HD .38-16 X 1.250
1098	JLGp-4071020	SHIM,.06X1.25X6.87 A569
1099	JLGp-4160026	SPRING, WASHER BELLEVILLE B1
1100	JLGp-4300092	STUD,.50-13.00-5.50 C1040 STL
1101	JLGp-4360092	switch, toggle
1102	JLGp-4360200	switch, toggle
1103	JLGp-4360202	switch, toggle
1104	JLGp-4360204	SWITCH, -TOGGLE
1105	JLGp-4360216	SWITCH, CIRCUIT BREAKER

1106	JLGp-4360266	SWITCH, LIMIT
1107	JLGp-4360301	SWITCH, LIMIT
1108	JLGp-4360462	SWITCH, POTENTIOMETER
1109	JLGp-4360579	SWITCH, ROLLER LEVER LIMIT
1110	JLGp-4360622	SWITCH, ROTARY TRANSDUCER
1111	JLGp-4400436	TANK, MOLDED FUEL TANK
1112	JLGp-4460481	TERMINAL, CONN PLUG
1113	JLGp-4460939	TERMINAL, 8 POS. DEUTSCH RECEP
1114	JLGp-4461007	TERMINAL,CONNECTOR
1115	JLGp-4565314S	tube HAX 150
1116	JLGp-4640005	VALVE, NEEDLE
1117	JLGp-4640509	VALVE, HOLDING
1118	JLGp-4640999	VALVE, NON VENTED C/BAL
1119	JLGp-4641086	VALVE, HOLDING 5;1
1120	JLGp-4641188	VALVE, POPETT, 2-WAY N.C.
1121	JLGp-4641248	VALVE, COUNTERBALANCE
1122	JLGp-4641390	VALVE, CHECK W/THERMAL RELIEF
1123	JLGp-4641510	VALVE, FLOW DIVIDER
1124	JLGp-4711600-100 : JLGp-4711600-100 : JLGp-4711600	Flat Washer 3/8" Narrow
1125	JLGp-4740263	WASHER, SPECIAL
1126	JLGp-4740538	WASHER-SPEC, THRUST, .125
1127	JLGp-4842046	WELD, SHAFT
1128	JLGp-4846558S	WELD, POWER TRACK SUPPORT
1129	JLGp-4846689	WELD, LOWER JIB LINK
1130	JLGp-4891800	WSH HARD .50 .526 1.125 .187
1131	JLGp-4922466	HARNESS, MAIN BOOM CABLE(600SJ)
1132	JLGp-4922526	HARNESS, PLATFORM CONTROL BOX
1133	JLGp-4922636	CABLE, JUMPER BOOM LIFTS
1134	JLGp-70000107	KIT, SEAL
1135	JLGp-70000255	O-RING
1136	JLGp-70000260	O-RING
1137	JLGp-70000506	ASSY, 2FT. REPAIR SECTION
1138	JLGp-70000817	O-RING, COVER
1139	JLGp-70001353	E-PROM W/SOFTWARE
1140	JLGp-70001380	KIT, SEAL
1141	JLGp-70001996	KIT, REPAIR SECTION (4 LINKS)
1142	JLGp-70002225	KIT, SEAL
1143	JLGp-70002248	KIT, SEAL
1144	JLGp-7000265	STUD
1145	JLGp-7000282	WASHER
1146	JLGp-7000284	RETAINING RING
1147	JLGp-7000285	RETAINING RING
1148	JLGp-70003043	KIT, MAIN LIFT MODULE
1149	JLGp-70003614	KIT, HYDRAULIC FILTER

1150	JLGp-70003630	VALVE, FLOW SANDWICH
1151	JLGp-70003707	COIL
1152	JLGp-70003972	CARTRIDGE
1153	JLGp-7000417	SOLENOID COIL
1154	JLGp-7000418	SOLENOID COIL
1155	JLGp-70004585	CARTRIDGE
1156	JLGp-70004586	CARTRIDGE
1157	JLGp-70004926	CARTRIDGE, PLATFORM LIFT (USE 70007566)
1158	JLGp-7000548	coil
1159	JLGp-7001625	KIT, SEAL
1160	JLGp-7001629	GUIDE
1161	JLGp-7001988	RING GEAR FOR 2780097
1162	JLGp-7002320	NLA - SEAT
1163	JLGp-7002321	POPPET
1164	JLGp-7002322	SEAT
1165	JLGp-7002326	ORIFICE
1166	JLGp-7002328	SPRING
1167	JLGp-7002329	SPRING
1168	JLGp-7002450	COIL
1169	JLGp-70026995	PIPE KIT, W/GASKETS & SCREWS
1170	JLGp-70031387	IDLER ROLLER
1171	JLGp-7003647	COIL
1172	JLGp-7003719	TORSION SPRING
1173	JLGp-7003722	SLIDELock REPAIR KIT-RSG HANDL
1174	JLGp-7003791	ACTUATOR
1175	JLGp-7003792	GRIP HALF (PLASTIC)
1176	JLGp-7003973	HANDLE, HALF
1177	JLGp-7004821	GUIDE TUBE ASSY
1178	JLGp-7005881	SEAL KIT
1179	JLGp-7006133	MTG FEET 1180181
1180	JLGp-7006138	PIN ASSEMBLY
1181	JLGp-7006148	MOUNTING FEET
1182	JLGp-7006152	PIN KIT
1183	JLGp-7006153	ONE FOOT SECTION
1184	JLGp-7006191	REPAIR SECTION
1185	JLGp-7007689	LOCKWASHER
1186	JLGp-7009395	FACE SEALS KIT
1187	JLGp-7010412	BEARING NUT
1188	JLGp-7010488	GEAR, SUN
1189	JLGp-7010924	MOTOR, 24V. (OHIO)
1190	JLGp-7011112	KIT, SEAL
1191	JLGp-7011342	CARTRIDGE
1192	JLGp-7012339	COIL
1193	JLGp-7012367	SHIM
1194	JLGp-7012371	SPRING, INNER

1195	JLGp-7012925	SEAL KIT
1196	JLGp-7012944	COIL, 3 PRONG
1197	JLGp-7012995	CARTRIDGE/LESS COIL
1198	JLGp-7013753	KIT, BRUSH & SPRING
1199	JLGp-7016322	WIPER
1200	JLGp-7016519	REPAIR SECTION
1201	JLGp-7016530	REPAIR SECTION (8")
1202	JLGp-7017092	PIN, DOWEL
1203	JLGp-7017213	GUIDE 3.00 X 1.50
1204	JLGp-7017496	KIT, SEAL
1205	JLGp-7019111	BEARING, GEARHEAD
		KIT, COIL 12V FLYING LEAD
		! Part no longer serviceable From JLG !
1206	JLGp-7020361	Alternative part available
1207	JLGp-7020365	KIT, SEAL
1208	JLGp-7020366	KIT, SEAL
1209	JLGp-7020530	ASSEMBLY, SWITCH
1210	JLGp-7020654	RELAY, 30AMP
1211	JLGp-7021341	RING, SNAP
1212	JLGp-7022818	ASSEMBLY, POTENTIOMETER
1213	JLGp-7023983	CARTRIDGE
1214	JLGp-7024194	KIT, BRAKE SEAL
1215	JLGp-7024369	KIT, 24" REPAIR SECTION
1216	JLGp-7024375	ELEMENT, FILTER
1217	JLGp-7024571	COIL
1218	JLGp-7024572	CARTRIDGE
1219	JLGp-7024732	STUD
1220	JLGp-7024856	COIL
1221	JLGp-7024931	RING, SNAP
1222	JLGp-7026018	PLUG, CAVITY
1223	JLGp-7026072	KIT, SEAL ...
1224	JLGp-7026107	KIT, SEAL ...
1225	JLGp-7026503	RING
1226	JLGp-7026507	PLUG, W/O-RING
1227	JLGp-7026508	PLUNGER, VALVE BLK
1228	JLGp-7026692	VALVE, SOLENOID USE 70007939
1229	JLGp-7026693	KIT, SEAL
1230	JLGp-7027204	VALVE, RELIEF
1231	JLGp-7027795 (USE DEUp-02959621)	Deutz EMR2 Control Module
1232	JLGp-80613008	GREASE FITTING
1233	JLGp-91414050	KIT, SEAL
1234	JLGp-H000013	OIL-LEVEL INDICATOR SIGHT GLAS

1235	JLGp-H000570	SHIMS FOR PRESSURE SWITCH
1236	KUBp-16851-63820	Ring Gear, Kubota, 16851-63822
1237	MECp-13527	Potentiometer PSE01368
1238	MECp-13724	Wheel Motor Bracket Weldment/MEC 3247
1239	MECp-3801	flat washer
1240	MECp-5737	slotted hex nut
1241	MECp-6318	Pin Repair Kit for Cable-MEC
1242	MECp-7160	Axle Bushing,Mec1932 (PSE01986)
1243	MECp-7656	Control Box Harness, PSE01366
1244	MECp-7714	tapered roll bearing
1245	MECp-7715	tapered roll bearing
1246	MECp-7716	Race Bridge Top
1247	MECp-7717	bearing tapered race
1248	MECp-8159	Seal Grease/PSE02312
1249	MECp-8343	valve, spool, pop, 2 way, NC w. man override
1250	MECp-8344	Fuse 200Amps
1251	MECp-8386	Latch
1252	MECp-8435	Spring centering joystick
1253	MECp-8595	Holding Valve, PSE01639
1254	MECp-8613	Seal Kit for MEC 2033/2633 Steer Cylinder (109970)
1255	MECp-8696	Switch Limit Micro V7
1256	MECp-8761	switch assy
1257	MECp-8914	Coil 24V
1258	MECp-90100	Wire Harness With Connector Control Box -MEC (PSE01614)
1259	MECp-90127	BREATHER ASSEMBLY (PSE04219)
1260	MECp-90715	BREAK ASSEMBLY PSE01670
1261	MECp-90729	Label, joystick directions (PSE02488)
1262	MECp-90815	Lift Cylinder Valve, PSE02033
1263	MECp-90845	pressure sensor
1264	MECp-90901	decal MEC
1265	MECp-90957	Coil, 24Volts, Double Spade with Diode
1266	MECp-90958	coil, 12V double spade w/ diode
1267	MECp-90968	valve, 2 way NC
1268	MECp-91002	coil, 24V
1269	MECp-9549	Key Switch (XB2-BG21)
1270	MECp-9996	Coil 24V
1271	OMMp-10M1460	Drive Joystick,Left - OMME2600
1272	OMMp-110158	Potential Meter (IOM1462). 5K, Omme code 51710071,
1273	OMMp-PL083800	Turntable At Basket-OMME
1274	PERp-U20996130	gasket Perkins
1275	PQA-1001094670S-R	Link Jib - Lower (450AJ SL#0300133085)
1276	PQA-1001106938-R	Platform Control Module (450AJ SL#0300133085)(Repaired)
1277	PQA-1001140278-R	Master Cylinder Assy (450AJ SL#0300133085)(Repaired)
1278	PQA-1001140279-R	Platform level cylinder Assy (450AJ SL#0300133085)(Repaired)

1279	PQA-1001149676-R	Ground Control module (450AJ, SL#0300133085)(Repaired)
1280	PQA-1001217779-R	Rotator Assy (450AJ SL#0300133085)(Repaired)
1281	PQA-104011407-CG2	alternator/nippondenso
1282	PQA-106785	Solenoid 24v OMME
1283	PQA-163211302-CG2	REGULATOR/MAGNETI MAREL
1284	PQA-1684070-R	Tower Boom Lift cylinder (450AJ SL#0300133085)(Repaired)
1285	PQA-1684140S-R	Telescope Cylinder (450AJ SL#0300133085)(Repaired)
1286	PQA-1684154-R	Main Boom Lift cylinder (450AJ SL#0300133085)(Repaired)
1287	PQA-3501CC014-CG2	Armature,12V
1288	PQA-3515CC004-IS1	Armature,12V
1289	PQA-3600385-R	Piston Pump Assy (450AJ, SL#300133085)(Repaired)
1290	PQA-4001CB038	Solenoid,12V
1291	PQA-411011602	armature bosch 12v
1292	PQA-42276WIX	Air Filter/JLG510
1293	PQA-451005103-CG2	housing
1294	PQA-4641176-R	Main Control Valve Assy (450AJ SL#0300133085)(Repaired)
1295	PQA-4641177-R	Valve Block Assy - Rotate/Level (450AJ SL#0300133085)(Repaired)
1296	PQA-46490	genie, RT, Liftlux air filter inner
1297	PQA-46672	Air Filter S125 - Baldwin RS3543
1298	PQA-4758KM	Air Filter - Genie 3369
1299	PQA-4810C0918-CG2	pinion
1300	PQA-51259	hydraulic filter MEC/BT839-10
1301	PQA-512600004-IS1	Planet Gear
1302	PQA-51546	Hydraulic Filter
1303	PQA-522600005-IS1	Lever Deutz Engine
1304	PQA-524000001-CG2	Fork/Leo23GT
1305	PQA-531001407-CG1	Brush Gear/Bosch
1306	PQA-531004403-CG2	brush gear (Perkins Starter)
1307	PQA-534001308-CG2	brush gear
1308	PQA-54010A035-CG2	Brush Gear-Perkins Starter Motor
1309	PQA-55A121002-CG2	6201 ball bearing
1310	PQA-6202	Alternator Bearing
1311	PQA-6203-2RS	Ball Bearing
1312	PQA-6204	Ball Bearing
1313	PQA-6303-2Z	bearing
1314	PQA-9.5 X 1025 FAN BELT	Fan belt -450AJ
1315	PQA-9.5X1350	belt
1316	PQA-9982	Valve Spool, 4 Way - 2033
1317	PQA-9995	Valve,Spool,4 way,3 Position(Drive)-MEC 1532/1932
1318	PQA-AX38	13x965 belt for Perkins
1319	PQA-CROSSLAND 522	perkins fuel filter/ff963/33166
1320	PQA-DE SPRG - 0300	valve spring
1321	PQA-DEUTZ PUMP	Deutz Pump Assembly/0427-2819
1322	PQA-FAB 18-R	Radiator Bolt Macking

1323	PQA-FAB SEAL 30	Hyd Shaft Seal 15GT
1324	PQA-FAB SEAL 35	Level Cylinder seal kit 62Z (823061GT)
1325	PQA-FF896	fuel filter 2 (holland lift)
1326	PQA-HYD SEAL	Steer Cyl Seal (00000038)
1327	PQA-HYDRAULIC SEAL S85	45X55X6 - MPN - 4605400
1328	PQA-NEEDLE BEARING	TA 50207
1329	PQA-OR175	Oring
1330	PQA-OR420	Oring - Rotary Coupling
1331	PQA-P111147741	Head Gasket
1332	PQA-P198416710	Dip Stick
1333	PQA-PUMP FRONT SEAL T	Teupen Front Seal
1334	PQA-STARTER SERV 1	Starter Motor Repair / Cummins (Hax-150)
1335	SNOp-005223-908	decal
1336	SNOp-009442-003	Plattform Lock
1337	SNOp-056069-006	WSHR STEEL FLAT WSHE M6 DIN125A
1338	SNOp-056069-008	Washer, Wear pad AB38
1339	SNOp-057392-000	Decal SWL Large/PSE01178
1340	SNOp-057584-000	Outer Hub Bearing
1341	SNOp-057663-000	Pivot Pin
1342	SNOp-062791-002	Latch Paddle, PSE01035
1343	SNOp-064444-000	Decal-Upright X32
1344	SNOp-065733-000	Thrust Pad 1/4"
1345	SNOp-066152-001	Steering Link Weldment LH, PSE03724
1346	SNOp-066544-010	Half Handle- Upright X32
1347	SNOp-066551-950	Decal Working Load (Ext Deck) ( Code 104)-Local
1348	SNOp-066556-900	Decal, Danger Above Code 101 Local
1349	SNOp-066557-950	Decals X32 Code 103 Local
1350	SNOp-066557-951	Max Load Platform Decal, 108410; Upright X32
1351	SNOp-066805-006	Emergency Stop-Upright X 32
1352	SNOp-067195-001	Decal Three Hazard (English), PSE02981; Upright X32
1353	SNOp-101210-000	Decal Hydrogen Gas/PSE01179
1354	SNOp-114071-001	Hydraulic Pump for 114071-000-X26/32 (PSE03416)
1355	SNOp-500302-000	Coil, Solenoid
1356	SNOp-500468-001	Mounting Elements,AB38
1357	SNOp-500468-002	Energy Chain
1358	SNOp-501449-000	flanged bushing 16mm
1359	SNOp-501882-002	Boot Steer
1360	SNOp-501973-000	Weldment Cage Link-AB38
1361	SNOp-502097-000	Spacer
1362	SNOp-502132-000	roller extension
1363	SNOp-502148-001	Wear Pad, 108362
1364	SNOp-502171-003	WWheel Hub,Rear/PSE03648-Upright X26/X32
1365	SNOp-502204-001	Gate Spring, PSE04181
1366	SNOp-502206-001	Insert, Gate Pivot; PSE04874

1367	SNOp-502453-000	Circuit Board (Upper Control Assembly), PSE03117, 501865-000 (USE SNOp-501865-000)
1368	SNOp-502483-000	ECU Box with PC Board (PSE01795)
1369	SNOp-502489-000	Line Contactor (PSE03789)
1370	SNOp-502495-001	Socket Main Harness (Old Pno. 502587-001)
1371	SNOp-502562-001	socket, over load/502605-000
1372	SNOp-503648-000	Gate Latch Weldment
1373	SNOp-503673-001	Plain Bushing, PSE03725
1374	SNOp-503687-000	steer cyl assy MX19/PSE03143
1375	SNOp-503724-000	Decal, WARNING CRUSHING
1376	SNOp-503755-000	Castle Nut (PSE03248)
1377	SNOp-503759-000	Latch Spacer,
1378	SNOp-504029-000	cable guide channel x32
1379	SNOp-504103-000	scissor weldment, outer
1380	SNOp-504120-000	flange bushing 50mm
1381	SNOp-504132-000	Pathhole Cylinder
1382	SNOp-504143-001	Spacer Steering, PSE04420
1383	SNOp-504144-000	Bushing, PSE01544, PSE06610
1384	SNOp-504148-000	Steer Cylinder
1385	SNOp-504155-000	Wear Pad, PSE03353, UP504155-001
1386	SNOp-504177-000	roller, torsion arm
1387	SNOp-504187-000	Access platform lock pins
1388	SNOp-504194-000	decal, livery X32N
1389	SNOp-504196-000	decal, Upright (PSE04387)
1390	SNOp-504199-001	Decal (504199-001)
1391	SNOp-504558-000	Module Load (107129)
1392	SNOp-504559-000	Angle/Height Sensor
1393	SNOp-504560-000	Pressure Transducer
1394	SNOp-505072-000	Proximity Switch IG5221, Replaced with 105435
1395	SNOp-505566-001	tilt sensor (058912-000)
1396	SNOp-512744-000	emergency lowering valve only
1397	SNOp-512745-000	valve & coil kit X32/26
1398	SNOp-513542-006	J1 Harness
1399	TEUp-302116	Control System-Leo23GT
1400	TEUp-302186	Plug-Leo23GT
1401	TEUp-302289	Bracket,Leveling-Leo23GT
1402	TEUp-3111/0106	Cylinder Engine Speed Control - Throttle Solenoid
1403	TEUp-3112/0195	Basket Level Cyl Seal Kit-LEO36T (SN:141216)
1404	TEUp-3112/0198	Track Level Cyl Seal Kit-LEO30T ( SN:140705)
1405	TEUp-3112/0263	Seal-kit, cylinder 140/80-1050
1406	TEUp-3112/0319	Main Lift Cylinder Seal Kit - LEO15GT(SN:140695)
1407	TEUp-3112/0523	Telescope Cyl Rod Piston-LEO36
1408	TEUp-3131/0022	ball valve for hyd tank Leo15GT
1409	TEUp-3141/0086	Hydraulic Pump,LEO25T
1410	TEUp-3141/0138	Hydr. pump-LEO12G/15GT, Honda



1411	TEUp-3152/0095	Valve Hyd Locking, 3152-0095, CBBALHN
1412	TEUp-3162/0036	HYDRAULIC FILTER
1413	TEUp-3191/0026	hyd pump drive assy (female)
1414	TEUp-3413/0101	Filter Element
1415	TEUp-3413-0178	Exhaust Muffler-LEO18GT ( SN: 140749 )
1416	TEUp-3531/0977	Mechanical stop-adjustable, pin
1417	TEUp-3531/2138	Bolt, 24 x 120 Leo 23GT
1418	TEUp-3701/0012	Joystick S-14 23GT
1419	TEUp-3715/0358	Relay-Leo23GT
1420	TEUp-3715/1274	Memory module-MCS167 + MCS892 (including RSS-0052 Program)
1421	TEUp-3715/1345	Battery Charger for Leo 30T W/Serial No.140705
1422	TEUp-3715/1598	LEO 23GT LIMIT SWITCH ATTACHMENT
1423	TEUp-3715/1771	LEO 23GT LIMIT SWITCH ROLLER
1424	TEUp-3715/1911	Synthesizer-receiver, CS434TRR-1
1425	TEUp-3916/0003	Rubber bumper(Ladder)
1426	TEUp-4001/0250	Level Bubble
1427	TVHp-754348	needle bearing X-32